



210 Rollin Coal Lane  
Woodbury, TN 37190

Phone - (615) 563-7800

www.bdpshop.com  
sales@bdpshop.com

## Micro Fuel Sump Installation Instructions

### What is included in the sump kit:

Sump with O-ring  
Mounting Bolt with sealing washer  
8 O-Ring Boss (ORB) to 1/2" QDC/Push-Lock Fitting  
Crescent Shaped Mounting Piece

### Tools needed for install:

Electric Drill  
7/32 Allen Socket  
7/8 Wrench  
Torque Wrench Recommended  
(up to 22 ft-lbs)  
Bucket to Drain Fuel Tank

- The first part of installation is to find a nice clean, flat spot on the bottom of your fuel tank where the sump will mount. For most applications, **we mount them directly underneath the stock fuel pickup assembly.** Please make sure that there are no ridges, letters, or anything that would cause the O-ring not to seal to the tank. **If you choose to mount directly under the pickup assembly it might be necessary to drill a hole through the bottom of the basket for the center bolt of the sump to protrude through so the sump bolt doesn't push up on the basket of the stock fuel pickup assembly.**
- Next clean the surface of the fuel tank where the sump will be mounted. The total area that needs to be flat is a 3" circle minimum.
- Use a 1-1/2" hole saw onto an electric drill and drill a hole in the bottom of the tank with the pilot bit of the hole saw for the fuel to drain.
- Once all of the fuel is drained from the tank, position the pilot bit of the hole saw into the same hole you drilled in the step above and drill a 1-1/2" hole with the hole saw.
- Clean out the inside of the tank to remove any plastic shavings that may have been introduced into the tank when you cut the 1-1/2" hole. You may even pour a gallon of fuel back into the tank and let it drain from the 1-1/2" hole to help clear any contaminants.
- Slide the crescent shaped piece of the sump into the tank via the 1-1/2" hole you just made. This can be done without removing the tank.
- Once the crescent shaped piece is in position, install the mounting bolt through the sump and thread the bolt into the crescent shaped piece that you installed in the steps above. Remember to have the O-ring positioned in the groove of the sump to ensure no leaks. (The crescent shaped piece can sit in any direction. But for peace of mind, install the crescent over the settlement bowl.)
- Recommended Torque of the mounting bolt is 22 ft-lbs. In some instances this doesn't crush the O-ring enough to seal against the tank. Normally, as long as the O-ring has a clean flat surface to seal against, this is not a problem. If there is a leak between the tank and the sump, use common judgment to tighten the bolt little more till it stops leaking be careful not to strip Allen head bolt.
- The supplied barb fitting can be used as a push lock fitting.
- **Coat fitting with a light coat of grease (before installing)** and torque to 22 ft-lbs. Or, hand-tighten and then tighten about 1/2 turn with a wrench.
- Connect your 1/2" supply line to the supplied fitting protruding from the sump. (If your line is not 1/2" you will need to purchase the correct size fitting for your system.)
- Refill your tank with fuel and inspect the sump and fuel line for any leaks.

We also have a full installation video on our website and our YouTube page that you can review as a visual aid.

The video link is <http://www.youtube.com/watch?v=RfFM51j5rJU&feature=youtu.be>